

ASSEMBLY INSTRUCTIONS:

 ω \sim . STRIP THE CABLE AS SHOWN. DO NOT NICK CENTER CONDUCTOR.

CAP (B)

STRIPPING DIMENSIONS

CRIMP SIZE REQUIRED CONTACT: SOLDER

FERRULE: .256 [6.5] HEX CRIMP TOOL

6.10

- SLIDE THE FERRULE (C) OVER THE CABLE JACKET.
- GROOVE (Y). THE CABLE BRAID MUST OVERLAP THE KNURLED LOOSEN THE CABLE BRAID, THEN INSERT THE CENTER CONDUCTOR INTO THE CONNECTOR (A) UNTIL IT APPEARS IN THE CONTACT SECTION OF THE CONNECTOR (A). SOLDER THE CENTER CONDUCTOR IN THE CONTACT GROOVE.
- **PLACE** SLIDE THE FERRULE (C) OVER THE CABLE BRAID AND CRIMP IN
- SCREW THE CAP (B) INTO THE CONNECTOR (A).

5

THESE COMMODITIES, TECHNOLOGY OR SOFTWARE WERE EXPORTED FROM THE UNITED STATES IN ACCORDANCE WITH THE EXPORT ADMINISTRATION REGULATIONS. DIVERSION CONTRARY TO U.S. LAW PROHIBITED.



an INFINIT® brand

TIT IE

