

- ASSEMBLY PROCEDURES
- STRIP CABLE AS SHOWN IN (A). DO NOT NICK DIELECTRIC
- 2. PRE-TIN CABLE JACKET TO APPROXIMATE DIMENSION AS SHOWN IN (B).
- INSERT CABLE THRU ADAPTER UNTIL IT BOTTOMS OUT. SOLDER OUTER CONDUCTOR TO ADAPTER & TRIM DIELECTRIC AS SHOWN IN (C).
- SCREW ASSEMBLY INTO BODY & TIGHTEN NUT.

	TITLE	FAIRVIEW MICROWAVE INC. ALLEN, TX 75013 WWW.FAIRVIEWMICROWAVE.COM
CAD FILE 080814 SHEET	DWG NO SC5860 CAGE CODE 3FKR5	NOTES: 1. UNLESS OTHERWISE SPECIFIED ALL DIMENSIONS ARE NOMINAL. 2. ALL SPECIFICATIONS ARE SUBJECT TO CHANGE WITHOUT NOTICE AT ANY TIME. 3. DIMENSIONS ARE IN INCHES [mm].
080814		
SHEET		
SCALE N/A		
SIZE A		
150		