



- 1. STRIP CABLE AS SHOWN, DO NOT NICK CENTER CONDUCTOR.
- 2. PLACE CONTACT OVER CENTER CONDUCTOR. SOLDER CONTACT TO CENTER CONDUCTOR.
- 3. INSERT CABLE INTO CONNECTOR BODY UNTIL OUTER CONDUCTOR BOTTOMS OUT. SOLDER OUTER CONDUCTOR TO BODY.

THESE COMMODITIES, TECHNOLOGY OR SOFTWARE WERE EXPORTED FROM THE UNITED STATES IN ACCORDANCE WITH THE EXPORT ADMINISTRATION REGULATIONS. DIVERSION CONTRARY TO U.S. LAW PROHIBITED.



an INFINITe brand

HITE

